



**AirBridge Rapid Network Infrastructure**

**ARNI DEPLOY QUICKSTART GUIDE**








## POWER TURNING ON



### Step 1

Ensure your Deploy unit is placed in a safe location with a clear view of the sky and free of any obstructions. ie. Trees, roofs, buildings.



### Step 2

Turn the battery isolation switch to the "ON" position.



### Step 3

Power on the inverter using the inverter remote of the front of your Deploy unit. Ensure the red indication light is lit.



### Step 4

Turn on REDVISION display (Skip time setting by pressing top right button twice).



### Step 5

Allow 5 minutes for all hardware to power on and connect to the Starlink Satellites.



### Step 6

Connect to the Wi-Fi with the provided credentials.

Contact us today to discover how AirBridge Networks can transform your disaster response efforts.

 1300 825 410  
arni.net.au





## POWER TURNING OFF



### Step 1

Turn off the REDVISION display by holding down power button.



### Step 2

Turn off Inverter using inverter remote of the front of the unit.



### Step 3

Turn the battery isolation switch to the "OFF" position.

## CHARGING VIA SOLAR



### Step 1

Connect foldable solar panel to ARNI Deploy with provided cable using the Red Anderson Input on the front of the unit.



### Step 2

Turn battery isolation switch to the "ON" position.



### Step 3

Power on the REDVISION Display to see real time charging data.

Contact us today to discover how AirBridge Networks can transform your disaster response efforts.

 **1300 825 410**  
[arni.net.au](http://arni.net.au)






## CHARGING VIA DC INPUT



### Step 1

Connect to DC source with the Grey Anderson Input on the front of the unit (cable not supplied).



### Step 2

Turn the battery isolation switch to the "ON" position.



### Step 3

Power on the REDVISION Display to see real time charging data.



### Step 4

Once charged, disconnect from your DC source, and turn isolation switch to the "OFF" position.

Contact us today to discover how AirBridge Networks can transform your disaster response efforts.

 1300 825 410  
[arni.net.au](http://arni.net.au)






## CHARGING VIA AC/MAIN POWER



### Step 1

Connect a 15amp extension lead into the AC input on the front of the unit.




### Step 2

Turn the battery isolation switch to the "ON" position.



### Step 3

Power on the REDVISION Display to see real time charging data.



### Step 4

Once charged, disconnect from your DC source, and turn isolation switch to the "OFF" position.

Contact us today to discover how AirBridge Networks can transform your disaster response efforts.

 **1300 825 410**  
[arni.net.au](http://arni.net.au)





**AirBridge Rapid Network Infrastructure**

**Contact us today and discover how AirBridge & Vocus can transform your business connectivity needs.**

 **1300 825 410**

**[arni.net.au](http://arni.net.au)**

